



GRANDIO®

G R E E N H O U S E S

INTERIOR FRAME TO BASE ANCHOR KIT



(GP-EZ1-BRACKET) FRAME TO BASE ANCHOR KIT PARTS LIST

IMAGE	PART	NAME	8 PACK	4 PACK
	S06/ML01	M6*16 NUT & BOLT COMBO	32	16
	EZ1	25 mm x 155 mm BRACE	8	4
	EZ2	25 mm x 25 mm x 75 mm BRACKET	8	4

EZ1 INSTALLATION

1.1 Pre thread the top two **S04/ML01** nut and bolt combos on the **EZ1**, see **A** .

1.2 See **B** . Slide **1. S04/ML01** nut and bolt combo into the entry notch to slide into the channel of the **602A** or other extrusion of choice, twist the **EZ1** then slide up the track to align **2. S04/ML01** nut and bolt combo with notch entry of channel. Slide **EZ1** down track to bottom to align with the base see **C** .

1.3 Slide **EZ2** into the base then twist into place, note the fit will be tight, align with the **EZ1**. See **B** **3.**

1.4 Insert the 2 remaining sets of **S04/ML01** nut and bolt combos so the nut faces you for tightening. See **C** .

Check that all nut and bolt combos are tightened. If this is installed where an L08C-X goes attach to the front of the EZ1 Nut and Bolt combo.

